

IPV Driver Protection 5 Step Guide

Scan Code
**Watch our
safety video**



Seat Forward Position

The seat should be moved forward so that you can operate all controls safely.

STEP
1



STEP
2

Seat Height

The seat height and steering wheel position should be set so that there is enough space to operate the controls safely.



STEP
3

Seat Back Position

If you have an adjustable head restraint it should be positioned where possible:

- *Close to the rear of your head*
- *Level with the top of your head*

The seat back should be reclined by **no more than 20 degrees**. The head restraint should be positioned close to the rear of the head.



STEP
4

Seat Belt Position

The seat belt should be worn at all times. It should be positioned across the pelvis and shoulder/collar bone, ensuring it is tight to the body.



STEP
5

Vehicle Cabin

Ensure your vehicle cabin is tidy and clear of unrestrained objects that will move in a collision.



